

Instructions for Culvert Installation

For your water to drain correctly and for your culvert to pass inspection these instructions need to be followed.

1. Purchase a culvert permit and pick up a stake with your address.
2. Measure out 30 ft in your ditch, where you want your driveway located, making sure you stay 25ft away from property lines.
3. Put the stake with your address number on your property line where you would like the center of your driveway to be (middle of the 30ft or 40ft) that you measured off for you culvert.
4. CCWCD will then send someone to survey the ditch and he will leave stakes at the outer edge of the 30ft marked with black lines.
5. If CCWCD writes CUT 2ft. Attach a string from one stake to the other. Making sure your string is set on the black line of each stake. Then measure from your string to the ground 2 ft. This is where the bottom of your culvert should be set. You may have to remove any debris in that may be in the way and place your culvert.
6. Once culvert is placed, please call for inspection of culvert before covering culvert.
7. Once culvert passes you may then cover your culvert with material, then please call the office to set up inspection.
8. If you have placed a home or building a home, you will then need a final swale and driveway inspection once the home is placed or built.
9. Also, if installing a fence, you will need to have an inspection of the swale to make sure it wasn't ruined in the process of the landowner installing a fence.

Instrucciones para la instalación de alcantarilla

Para que su agua drene correctamente y para que su alcantarilla pase la inspección, se deben seguir estas instrucciones.

1. Compre un permiso de alcantarilla y recoja una apuesta con su dirección.
2. Mida 30 pies en su zanja, donde desea que se encuentre su camino de entrada, asegurándose de mantenerse a 25 pies de distancia de las líneas de la propiedad.
3. Coloque la estaca con su dirección en el medio de los 30 pies que midió para su zanja.
4. CCWCD enviará a alguien a inspeccionar la zanja y dejará estacas en el borde exterior de los 30 pies marcadas con líneas negras.
5. Si dice CUT 2ft. Coloque una cuerda de una estaca a la otra. Asegúrese de que la cuerda esté colocada en la línea negra de cada estaca. Luego mida desde su cuerda hasta el suelo 2 pies. Aquí es donde debe colocarse la inversión inferior de su tubería.
6. Cuando haya terminado de instalar su alcantarilla, llame a la oficina para configurar la inspección.
7. Una vez que pase la alcantarilla, puede cubrir su alcantarilla con material, luego llame a la oficina para programar la inspección.
8. Si ha colocado una casa o una casa construida, necesitará una inspección final de la zanja y el camino de entrada una vez que se coloque o construya la casa.
9. Además, si instala una cerca, deberá realizar una inspección de la zanja para asegurarse de que no se haya arruinado en el proceso de instalación de una cerca por parte del propietario.

Office/Oficina # (863) 983-5797